


ROVI[®]

SPINDLE WORK STOP




WORK STOP

The SPINDLE WORK STOP is an expanding tool that fits into a lathe spindle or draw tube for quick setup when accuracy or consistency of linear dimensions is necessary.

To Install:

Step 1. Place work piece in chuck or collet and set proper length.



Step 2. Insert work stop into rear of spindle or draw tube. Expand fingers until they touch spindle; then back off screw quarter turn.



Step 3. Using "T" wrench, slide work stop into spindle until it contacts with work piece. Tighten work stop and remove wrench.



RANGE	CAT. NO.	PRICE
3/4" - 7/8"	44000	\$185.00
1" - 1 1/8"	44001 5C Style	120.00
1 1/8" - 1 1/4"	44002	120.00
1 1/4" - 1 3/8"	44003	120.00
1 3/8" - 1 1/2"	44004	120.00
1 1/2" - 1 5/8"	44005	145.00
1 5/8" - 1 3/4"	44006	145.00
1 3/4" - 1 7/8"	44007	145.00
1 7/8" - 2"	44008	145.00
2" - 2 1/8"	44009	160.00
2 1/8" - 2 1/4"	44010	160.00
2 1/4" - 2 3/8"	44011	160.00
2 3/8" - 2 1/2"	44012	160.00
2 1/2" - 2 5/8"	44013	185.00
2 5/8" - 2 3/4"	44014	185.00
2 3/4" - 2 7/8"	44015	185.00
2 7/8" - 3"	44016	185.00
3" - 3 1/8"	44017	225.00
3 1/8" - 3 1/4"	44018	225.00
3 1/4" - 3 3/8"	44019	225.00
3 3/8" - 3 1/2"	44020	225.00
3 1/2" - 3 5/8"	44021	265.00
3 5/8" - 3 3/4"	44022	265.00
3 3/4" - 3 7/8"	44023	265.00
3 7/8" - 4"	44024	265.00
4" - 4 1/8"	44025	305.00
4 1/8" - 4 1/4"	44026	305.00
4 1/4" - 4 3/8"	44027	305.00
4 3/8" - 4 1/2"	44028	305.00
4 1/2" - 4 5/8"	44029	365.00
4 5/8" - 4 3/4"	44030	365.00
4 3/4" - 4 7/8"	44031	365.00
4 7/8" - 5"	44032	365.00

ROVI[®]
PRODUCTS
INCORPORATED

4685 Runway Street #G • Simi Valley, CA. 93063
(805) 582-0165 • FAX (805) 582-1530
Outside CA (800) 423-5145